

PROJECT EV



APEX-7.3

Instruction Manual

APEX-7S / APEX-7S-4G / APEX-7S-T / APEX-7S-T-4G

Contents

Safety Information	3
Packaging List	5
Product Information	6
Product Data	7
Installation	8
The APEX App	14
Anti-Tamper Switch	16
Charging Mode and Operation	19
Maintenance	21
Warranty	23

Contact Information

www.projectev.co.uk











enquiries@projectev.co.uk
0333 733 0333

Project EV,
Unit 1 Lakes Court,
Lancaster Park,
Newborough Road,
Burton-On-Trent
DE13 9PD

Safety Information

Project EV chargers are designed and tested in accordance with international safety requirements. However, certain safety precautions must be taken when installing and operating this. The installer must read and follow all instructions, cautions and warnings in this installation manual.

- All operations including transport, installation, start-up and maintenance, must be carried out by qualified, trained personnel.
- The electrical installation & maintenance of the charger shall be conducted by a licensed electrician and shall comply with local wiring rules and regulations.
- Before installation, check the unit to ensure it is free of any transport or handling. Unauthorized removal of necessary protections, improper use, incorrect installation and operation may lead to serious safety and shock hazards or equipment damage.
- Do not install the equipment in adverse environmental conditions such as in close proximity to flammable or explosive substances; in a corrosive or desert environment; where there is exposure to extreme high or low temperatures; or where humidity is high.
- Do not use the equipment when the safety devices do not work or are disabled.
- Use personal protective equipment, including gloves and eye protection during the installation.
- Inform the manufacturer about non-standard installation conditions.
- Do not use the equipment if any operating anomalies are found. Avoid temporary repairs.
- All repairs should be carried out using only approved spare parts, which must be installed in accordance with their intended use and by a licensed contractor or authorized Project EV service partner.
- Liabilities arising from commercial components are delegated to their respective manufacturers.

	Danger - Danger indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	Warning - Warning indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	Caution - Caution indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
	CE - The charger complies with the requirements of the applicable CE guidelines.
	UKCA - The charger complies with the requirements of the applicable UKCA guidelines.
	Beware of hot surface - The charger can become hot during operation. Avoid contact during operation.
	Danger of high voltages - Danger to life due to high voltages in the charger.
	Danger - Risk of Electric Shock
	Read the manual carefully.
	Product should not be disposed as household waste.

Safety Information

Product Handling

To ensure safety, the following points should be paid attention to:

- All accessories are placed separately during transport or handling.
- Avoid violent shock and impact.

Out of the box inspection

- Please open the charging pile packaging and verify all parts according to the attachment list.
- Check the charging pile for damage in transport. If damage or missing parts are found, do not install and inform the carrier and dealer. Determine if this machine is the model that you want to purchase.
- Note: Please keep the packing boxes and packaging materials for future handling.

Install

- Pre-installation preparation

The following tools are required for the installation:

Screwdriver, spirit level, cable strippers, crimping pliers

- Installation precautions


Please strictly follow the wiring requirements and correct access. Please confirm that all fasteners are locked to secure the charging pile.

- Installation placement environment and location


- The area where the charger must be placed must be well ventilated, far away from water, combustible gas and corrosive agent.
- Ensure that the ground or installation platform can withstand the weight of the charger.
- If the charger is disassembled and used at low temperature, there may be ingress of moisture, be sure to wait for the charger to be completely dry. After dryness can be installed and use, otherwise there is a danger of electric shock.
- Please place the charger near the mains input or near an isolation switch to disconnect and cut off the power supply in an emergency.

Note: The actual installation needs to comply with current wiring regulations and local safety regulations.


Ensure that the wall or column is vertical or positive 15 ° before installation.



Vertical



Front




Tilt Back




Tilt Flat


Packaging List



EV Charger
Quantity: x1




Mounting Backplate
Quantity: x1




Mounting Bracket
Quantity: x1




RFID Card
Quantity: x2




Wall Plugs
Quantity: x4




Fixing Screws
Quantity: x4




Ferrule Crimp Connectors
Quantity: x3




Assembly Screws
Quantity: x2



Self Tapping Screw
Quantity: x2




CT Clamp
Quantity: x1




**Eastron SDM120 ct
- MID Approved**
Quantity: x1

Product Introduction

Tethered Charger







Untethered Charger



Product Data

	APEX-7S-T / APEX-7S-T-4G Tethered	APEX-7S / APEX-7S-4G Untethered
Input		
Wiring Scheme	1P+N+PE	1P+N+PE
Voltage	230Vac, ±20%	230Vac, ±20%
Maximum Current	32A	32A
Frequency	50/60Hz	50/60Hz
Output		
Voltage	230Vac, ±20%	230Vac, ±20%
Maximum Current	32A	32A
Rated Power	7.3kW	7.3kW
User Interface & Control		
Connector Type	Type 2 Cable	Type 2 Socket
Cable Length	5m	N/A
RFID Reader	Mifare ISO/IEC 14443 A	Mifare ISO/IEC 14443 A
Start Mode	Plug & Play/ RFID Card/ App	Plug & Play / RFID Card / App
Communication		
WiFi	Yes*	Yes*
Bluetooth	Yes	Yes
LAN	Available Q1 2024	Available Q1 2024
4G	4G on APEX-7S-T-4G Only	4G on APEX-7S-4G ONLY
OCPP	OCPP 1.6 J2ON, OCPP 2.0 Optional (Coming Soon)	OCPP 1.6 J2ON, OCPP 2.0 Optional (Coming Soon)
<small>*Range capability up to 30m. Dependent on environment and charger location/surroundings.</small>		
Environment		
Installation	Wall-Mount / Post-Mount	Wall-mount / Post-mount
Operating Temperature	-30°C ~ 50°C	-30°C ~ 50°C
Operating Humidity	5% ~ 95% No Condensation	5% ~ 95% No condensation
Operating Altitude	≤2000m	≤2000m
Mid Metering / CT	EN50470-1 & EN50470-3 Class B MID approved Meter (pre configured) (CT Clamp and Meter Included)	
Safety		
IP Protection Rating	IP55	
IK Protection Rating	IK08	
Residual Current Detection	Integral Type A RCBO / AC 30mA / DC 6mA	
Over Current Protection	✓	
Residual Current Protection	✓	
Pro Earth Pen Fault Protection	✓	
Surge Protection	✓	
Over Voltage protection	✓	
Under Voltage Protection	✓	
Over Temperature Protection	✓	
Under Temperature Protection	✓	
Certification	CE, UKCA	
Certification Standard	EN/IEC 61851-1: 2019, EN/IEC 61851-21-2: 2021	
Dimension And Weight		
Product Dimension	320*190*144 mm	320*190*144 mm
Product Weight	5.6kg	2.4kg
Product Colour Options*		
<small>*APEX-7S chargers are 'EV Steel' colour as standard. Further colour options are available upon request, subject to availability.</small>		
Mounting & Accessories		
Floor Pole	Opt. APEX-SPOST	Opt. APEX-SPOST




Installation

Wall-Mounted Installation Method:


1. Open the package and mark 4 holes in the wall ($\varnothing 8 * 50\text{mm}$).
2. Fit into the wall plug.
3. Attach the mounting backplate with screws to the mounting wall.
4. Attach the bracket to the charger.
5. Hang the charger into the mounting back plate and screw it.
6. Installation completed.

Note: Installation wall angle $90^{\circ}\pm 15$, thickness $> 50\text{mm}$



Removing the Base Cover Plate to Change Colour

1. Using a flat-headed screwdriver, push in the tabs connecting the front plate to the charging unit. There are 10 tabs in total, located in the red positions below.









Installation

Post Mounted Installation Method (Using Additional Product Code APEX-SPOST)

1. Drill holes on the concrete or solid floor, four 165 * 95 holes with diameter ϕ 10mm deep 50mm screws and one ϕ 60mm through duct hole.
2. Install and fix the anchor screws.
3. The mains cable runs through the column hole through the bottom of the column.
4. Install the backplane is fixed to the landing column with screws.
5. Attach the bracket to the charger.
6. Hang the charger into the mounting back plate and secure it.
7. Installation completed.

Note: The angle of cement ground $90^{\circ}\pm 15$



Please Note: These instructions are only applicable when using APEX-SPOST






Installation

Electrical Connection

Step 1: Insert mains cable into the gland.

Step 2: Open the side cover, insert the cable and tighten the gland.


Step 3: Unscrew the terminal screws. Terminate cables, and replace the side cover.



Installation

Network Connection - Ethernet*

The network cable interfaces of the charging pile are as follows:



PIN	1	2	3	4	5	6	7	8
Color	White/Orange	Orange	White/Green	Blue	White/Blue	Green	White/Brown	Brown

*The availability of network connectivity is dependent on the model variant.

Installation




Network Connection - Ethernet*

Step 1: Pass the network cable through connector (K) and connect the network cable to the RJ45 connector.

Step 2: Unscrew the dust cover.

Insert the RJ45 communication connector on which the network cable is installed into the Ethernet port.

Step 3: Tighten the connector nut to complete the installation.



*The availability of network connectivity is dependent on the model variant.




Installation

Network Connection - 4G*

Step 1: Open the front cover

Step 2: Open the SIM Card plug and insert the SIM Card (When inserting the SIM Card, pay attention to the direction shown in the picture)

Step 3: Close the SIM Card plug, install the cover, and complete the installation.




*The availability of network connectivity is dependent on the model variant.

*Access Point Name (APN) will be required for the specific Sim Card.




DOWNLOADING THE APP

Download the APEX app from the Google Play or Apple app store.



Registering an account


1. Select the country where you would like the account registered to.
2. Press Register to enter registration page.
3. Fill in all details provided, and enter verification code sent to your email address.



The APEX App



Adding a chargepoint

1. Click on the add button, and scan the QR code or enter the serial number located on the side of the chargepoint. Enter a nickname for the chargepoint. Your charger will then appear on the screen as shown below.



Adding the chargepoint to a network


1. Click on the three dots in the right corner of the screen.
2. On the drop down menu, click on network.
3. Choose either WIFI or 4G depending on which unit chosen and enter details.
4. Access Point Name (APN) will be lot.1nce.net if you are using a Project EV purchased Sim Card.
5. The charger will now be connected to a network.



The APEX App

Adding an RFID Card

1. Click on the three dots in the right corner of the screen.
2. On the drop down menu, click on Whitelist.
3. Click Add to add an RFID card to the account.



Anti Tamper Switch

In December 2022, regulations were enforced for all chargepoints to be installed with an anti-tamper switch for security measures. If the side door of the unit is not secured properly, the anti-tamper switch will remain active. Please make sure the side door of the unit is securely shut, after the installation process is complete.


If fault persists, please contact technical@projectev.co.uk



The APEX App


Accessing the settings menu

1. Click on the three dots in the right corner of the screen.
2. On the drop down menu, click on settings.
3. Adjust all settings required.



Upgrading Firmware




1. Click on the three dots in the right corner of the screen.
2. On the drop down menu, click on upgrade.
3. Select the firmware you want to upgrade to.



The APEX App

Scheduling a charge

1. Click on the three dots in the right corner of the screen.
2. On the drop down menu, click on settings.
3. Press Timing Charging.
4. For a one time schedule, press add single and enter the scheduled charge time.
5. For a regular cycle, press add cycle and choose the days and times of the scheduled charge times.



Off-Peak Random Start Function


When a user adds a booking start record, the app will randomly add 0-10 minutes to the start time set by the user. The charging post then randomises another 0-59 seconds on to the start.

Charging Mode and Operation

Users can set three charging modes through the charging mode setting interface of the APP: controlled, locked, plug and charge.

A. Plug & Charge

Charging will start automatically after EV plugged in. If you want to stop the charging, just press the stop button on the side of the charger.



• Start Charging:


1. Set the charger to the Plug and Charge mode
2. Insert the charging plug into the EV
3. Charging session started

• Stop Charging:

Press the stop button on the side of the charger.

B. RFID

Initiate or cease charging by using APP or by swiping RFID card on this mode. You can also use APP for Reservations.



The controlled mode with RFID card

• Start Charging:

1. Set the charger to the Controlled mode
2. Insert the charging plug into the EV
3. Swipe card
4. Waiting for authorizing
5. Charging session started

Charging Mode and Operation

• Stop Charging:

1. Swipe card
2. Charging session end

C. App Mode

• Start Charging:


1. Set the charger to the Controlled mode
2. Insert the charging plug into the EV
3. Click to Start the Charge on the APP
4. Waiting for authorizing
5. Charging session started

• Stop Charging:

1. Click to Stop the Charge on the APP
2. Charging session end

D. Locked Mode

On this mode, the charger is locked and cannot be used.



Charging Status Indicators

LED Indicator Description	Definition
Green Flashing	Device Available
Blue Steady	EV Connected - User not authorised
Blue Flashing	Authorised - Wait for charging
Blue Rotating Light	Charging
Blue Flashing	Charging Suspension
Green Steady	Charging Finish - Wait for Unplug
Yellow Steady	Charging Locking
Red Steady	Device Fault

Maintenance



Troubleshooting

If fault occurs, users can check the fault information on the APP.

Fault Code on App	Solution
Electronic Lock Fault	Set the electronic lock status to the correct position. Or seek help from us.
Emergency stop fault	Reset the emergency stop button. Or seek help from us.
Abnormal CP voltage	Seek help from us.
Abnormal AC output contactor	Seek help from us.
Over current	Reduce output current. Or seek help from us.
Over voltage	Wait for the grid voltage to return to normal. Or seek help from us.
Undervoltage	Wait for the grid voltage to return to normal. Or seek help from us.
Electric leakage	Seek help from us.
Reverse connection of lin N	Correctly connect P and N lines. Or seek help from us.
Anti Tamper Switch	Wait for the anti tamper switch to return to normal. Or seek help from us.
Over temperature of charging interface	Wait for the temperature of charging interface to return to normal. Or seek help from us.

Finding a Fault

1. Click on the three dots in the right corner of the screen.
2. On the drop down menu, click on faults.
3. Check the faults list to find out which fault is happening.



Meter and CT Clamp Installation




CT clamp for solar or load balancing gets installed around the live cable from the main fuse. The arrow points to the flow of electricity, and when solar is producing, the CT registers this as a minus figure. This is how the charger knows the difference between mains and solar.




Please Note:

- There is a fly lead of 3m.
- If this is not installed correctly the charger will not see solar generation.
- Terminals (located on charger): RS485A and RS485B
- This needs to match with numbers 9 and 10 on the meter



Set upper limit to required value



Warranty

Limited Warranty Policy – APEX Series

i. Scope of Warranty

Please see www.projectev.co.uk for warranty information.





enquiries@projectev.co.uk
0333 733 0333

www.projectev.co.uk

Information correct as of 18/03/2024 [V4.17]